



# Unconventional Gas Lift

Angel Wileman, Dr. Eduardo Pereyra,  
Larry Harms, Dr. Paulo Waltrich,  
Tom Nations, Wayne Mabry


ALRDC Gas Lift Workshop  
June 7<sup>th</sup>-11<sup>th</sup> 2021




## Section 4.5

# True Valve Performance

# Typical Performance of Orifice Valve



# Typical Performance of IPO Gas Lift Valve




# Gas Lift Valve Sizing Methods

Artificial Lift  
R&D Council



Correlation	Valve Type	Availability
VPC	All types	Proprietary
TUALP	IPO	Public Domain
Bertovic	PPO	Public Domain
API Simplified	IPO	Public Domain
Winkler-Eads	IPO	Public Domain
Thornhill-Craver	Orifice only	Public Domain

# Compare Correlations



# Benefits of True Valve Performance

- ▶ Better installation designs
- ▶ Quicker unloading & kickoff
- ▶ Equipment design improvements
- ▶ Easier troubleshooting

Artificial Lift  
R&D Council



# Valve Performance Clearinghouse

Artificial Lift  
R&D Council



## Project Summary

- ▶ Consortium established in 1997.
- ▶ Full-scale testing of commercially-available gas-lift valves and development of custom correlations.
- ▶ COP member since 2004.
- ▶ 8 Member Companies.
- ▶ 4 Limited license-holders.

## Benefits

- ▶ Provides true valve performance of virtually all commercially available gas-lift valves.
  - ▶ Key enabler for design, trouble-shooting and optimization of gas-lift installations.
- ▶ All 216 correlations available to any member company employee.
  - ▶ Note: Individual licensees pay \$1700 per valve/port size combination.
- ▶ Proprietary software distributed to all member companies.
- ▶ Integrated with all major nodal analysis and design software.
  - ▶ Prosper, WellFlo, PipeSim, SNAP, WinGlue, WEM, OLGA.



ConocoPhillips



ExxonMobil



## Highlights


- ▶ 59 Valve models and 216 valve/port combinations tested since inception.
- ▶ Thousands of flow tests conducted.
- ▶ 2-3 new models tested each year.
- ▶ In 2015, administration shifted from Decker Technology to LSU.
- ▶ New flow loop at LSU.
- ▶ Greatly enhanced operating envelope at new test facility. (Higher rates and pressures.)

## Participation and Contract

- ▶ \$15K per year
- ▶ Cycles are annual starting January 1<sup>st</sup>
- ▶ One board meeting per year to review previous year's results and nominate next year's valves for testing. Held in Houston area at member facility.
- ▶ At-will termination. Following termination, renewal requires payment of following year's dues plus previous year's dues. (\$30K total)



# Dynamic Flow Loop



Artificial Lift  
R&D Council



# Key Operational Parameters

- ▶ Load Rate
- ▶ Stem Travel
- ▶ Flow Coefficient



# Load Rate


- ▶ A measure of the valve stem's resistance to movement. (psi/inch)
- ▶ One of the *MOST* important GLV performance parameters.
- ▶ Nearly constant for a given valve model (i.e. BK).
- ▶ Slightly lower for used valves than new valves.

# Typical Load Rate Test Data

Artificial Lift  
R&D Council



Test Pressure (Psig)






## Load Rates - Nitrogen vs Spring

- ▶ Load rates of nitrogen charged valves are a function of the set pressure.
- ▶ Load rates of spring loaded valves are nearly constant.
- ▶ Typically, spring loaded valves have much higher load rates than nitrogen charged valves therefore...

*For the same pressure conditions, nitrogen charged valves will come farther open than spring loaded valves.*

# Load Rates by Valve Type

Typical Gas Lift Valve Load Rates






# Effective Stem Travel

- ▶ Effective stem travel: The amount the stem can move away from the seat within the linear portion of the load rate curve.
- ▶ A function of set pressure for valves with internally charged bellows.
- ▶ The higher the set pressure, the lower the effective stem travel.
- ▶ For externally charged bellows, the effective stem travel is constant regardless of set pressure.



# Stem Travel for Full Open Port

Artificial Lift  
R&D Council






# Bellows Stacking

- ▶ Occurs when the outer convolutions come in contact with each other.
- ▶ Causes load rate to increase dramatically.
- ▶ Reduced stem travel and throughput.
- ▶ Once lost, effective stem travel can not be recovered.

# Internally Charged Bellows



# Damaged Bellows After Aging

Artificial Lift  
R&D Council






# Flow Coefficients

- ▶ Measure of the flow capacity
- ▶ A function of port size and stem travel.
- ▶ Constant regardless of whether valve is new or used.
- ▶ Flow coefficient test also determines when valve “chokes”.
- ▶ High set pressures may cause outer convolutions to balloon, limiting effective stem travel.

# Typical Flow Coefficient Curve

Flow Coefficients (Cv)



Artificial Lift  
R&D Council







# Vibration Dampening


- ▶ GLV's tend to "chatter" when throttling. The liquid fill in the dome is used to suppress the chatter.
- ▶ The liquid fill is usually Silicone fluid. Silicone fluid is very temperature sensitive and expands at five times the rate of water.
- ▶ Silicone fluid in dome WILL increase set pressure more than normal temperature correction.
- ▶ The more silicon fluid, the more the set pressure will increase.

# Silicone Fluid vs. Set Pressure

Artificial Lift  
R&D Council




Increase in Set Pressure (Psig)




# Top Valve with Range of Injection Pressures

Artificial Lift  
R&D Council






## Sensitivity to upstream pressure: port = 24/64




## Sensitivity to upstream pressure: port = 16/64

Artificial Lift  
R&D Council




## Sensitivity to upstream pressure: port = 12/64

Artificial Lift  
R&D Council



# Is this valve open?


Artificial Lift  
R&D Council




Valve Performance Clearinghouse  
Camco\_BK

GL Example.snp


2014 parameters  
07-Jul-16 14:57:16  
Valve Depth = 3554 ft




# Unloading Valve Performance



# Choked IPO Valves



# Choked IPO Valves





The upward movement of the valve stem with increasing tubing pressure is referred to as:

- A. Throttling
- B. Chattering
- C. Stacking
- D. Unloading




For a given port size, an IPO valve will have greater throughput than an orifice.

- A. True
- B. False





Which correlation provides the most accurate gas passage predictions for an IPO valve?

- A. Thornhill-Craver
- B. Bertovic
- C. TUALP
- D. Winkler-Eads
- E. API Simplified
-  F. VPC



Which valve will have the higher load rate?

A. BK with  $P_{tro} = 1000$  psig

😊 B. BK with  $P_{tro} = 1200$  psig



For a given port size and set pressure, which will have the greatest effective stem travel?

A. Camco BKF-12

B. Camco BK

 C. Camco R-20



A new valve will have a higher flow coefficient than a used valve.

A. True



B. False



# Which of these will improve an IPO valve's gas passage?

- A. Smaller bellows area
- B. Smaller port size
- C. More liquid fill in dome
- 😊 D. Downstream choke
- E. Bellows stacking

# Break

- ▶ Stretch and move!
- ▶ Please return in 15 minutes.



# Copyright

Rights to this presentation are owned by the company(ies) and/or author(s) listed on the title page. By submitting this presentation to the Gas-Lift Workshop, they grant to the Workshop, the Artificial Lift Research and Development Council (ALRDC) rights to:

- ▶ Display the presentation at the Workshop.
- ▶ Place it on the [www.alrdc.com](http://www.alrdc.com) web site, with access to the site to be as directed by the Workshop Steering Committee.
- ▶ Links to presentations on ALRDC's social media accounts.
- ▶ Place it on an USB/CD for distribution and/or sale as directed by the Workshop Steering Committee.

Other uses of this presentation are prohibited without the expressed written permission of the company(ies) and/or author(s) who own it and the Workshop Steering Committee.







# Disclaimer

The following disclaimer shall be included as the last page of a Technical Presentation or Continuing Education Course. A similar disclaimer is included on the front page of the Gas-Lift Workshop Web Site.

The Artificial Lift Research and Development Council and its officers and trustees, and the Gas-Lift Workshop Steering Committee members, and their supporting organizations and companies (hereinafter referred to as the Sponsoring Organizations), and the author(s) of this Technical Presentation or Continuing Education Training Course and their company(ies), provide this presentation and/or training material at the Gas-Lift Workshop "as is" without any warranty of any kind, express or implied, as to the accuracy of the information or the products or services referred to by any presenter (in so far as such warranties may be excluded under any relevant law) and these members and their companies will not be liable for unlawful actions and any losses or damage that may result from use of any presentation as a consequence of any inaccuracies in, or any omission from, the information which therein may be contained.

The views, opinions, and conclusions expressed in these presentations and/or training materials are those of the author and not necessarily those of the Sponsoring Organizations. The author is solely responsible for the content of the materials.

The Sponsoring Organizations cannot and do not warrant the accuracy of these documents beyond the source documents, although we do make every attempt to work from authoritative sources. The Sponsoring Organizations provide these presentations and/or training materials as a service. The Sponsoring Organizations make no representations or warranties, express or implied, with respect to the presentations and/or training materials, or any part thereof, including any warranties of title, non-infringement of copyright or patent rights of others, merchantability, or fitness or suitability for any purpose.