



**2025 GAS LIFT  
WORKSHOP**

**ExxonMobil**

# Alternate Gas Lift Tracer Pilots

## Radioactive / Minimum Concentration Tracers

**Michael Romer and Adrian Lejeune** – ExxonMobil Technology and Engineering

**William Mixon and Andrew Booton** – Tracerco

**Kurt Pacey** – Inficon

**Mitch VonBorstel** – Welker



**ALRDC.COM**

## Outline


### Background

- CO<sub>2</sub> Tracing
- Alternate Tracing

### Pilots, Round 1

- Hawkins
- Radioactive (RA) Tracing
- Minimum Concentration Tracing

### Next Steps





# 2025 **GAS LIFT WORKSHOP**


## Background



## CO<sub>2</sub> Tracer Surveys – Overview

### WellTracer®

- Inject a slug of CO<sub>2</sub> with GL gas
- Detect CO<sub>2</sub> returns with gas chromatograph
- Real-time data plus nodal analysis determines communication depth(s)
- Preferably at GL valves but could be a hole
- EM has run CO<sub>2</sub> tracer surveys for ~20 years
- (See References)




## CO<sub>2</sub> Tracer Surveys – Example

8/2010 – Well multipointing at first five mandrels; injection rate 43% higher than design

5/2011 – Injection rate reduced to design, lift at second and fifth mandrels

5/2012 – Multipoint injection at 3rd, 5th, and 6th valves; valves redesigned

1/2014 – Redesigned valves (ports and pressure settings) and reduced injection rate by 46%; production increase of ~550 BOEPD





## CO<sub>2</sub> Tracer Surveys – Pros/Cons

### Advantages

- Interventionless determination of communication points
- No production impairments during survey
- Field proven, commercial equipment



### Disadvantages

- Potential freezing issues due to sampling line (East Canada, Bakken, North Slope)
- Need enough CO<sub>2</sub> (pph) to overcome natural background (North Slope)
- Need enough pressure to inject into the GL gas stream (3000 psi in East Canada)
- Logistics of measurement unit, CO<sub>2</sub>, N<sub>2</sub> (for pressurization), hoses, laptops, etc.
- Considerations for area classification, exhaust stream, SIMOPS



## Potential Improvements

### Radioactive Tracer


- Hire somebody with a license!
- Inject the gas tracer with the GL gas
- Measure it through the flowline (no sampling!)
- High measurement sensitivity, shorter half-life, and dilution mitigate safety concerns



Tracerco Kr-79

### Minimum Concentration Tracer

- Inject something inert and alien to production wells
- Use a high-res (ppb/ppm) mass spectrometer (MS) to sample
- SF<sub>6</sub> recommended (common in facilities tracing)
- Argon easy to find but too close to hydrocarbon spectra, as confirmed with sample testing at Inficon





# 2025 GAS LIFT WORKSHOP

## Hawkins Field






# 2025 GAS LIFT WORKSHOP

USGS Map,  
Hawkins field  
shaded

## Hawkins Field


### History

- East Texas conventional, producing since 1940s
- Initially strong water drive (1st), then gas drive (2nd)
- Double displacement process since 1994 (3rd)
- Heavy oil with “asphalt” mat
- Bail water and inject gas to keep oil at perfs




### Artificial Lift Methods

- Gas Lift (mostly N<sub>2</sub>!)
- ESPs
- Jet pumps (few)
- Plungers (briefly)





## Hawkins Double Displacement Process









# 2025 GAS LIFT WORKSHOP

## Hawkins #1 Pilot



## Hawkins #1 Baseline

- < 100BPD liquids, ~480 MCFD GL gas
- Three 12/64" IPOs, no orifice
- Nodal: Top valve closed, middle valve in transition, bottom valve open
- CO<sub>2</sub> Tracer: All valves taking gas, WHP was ~260psi due to stuck choke








## Hawkins #1 RA Tracing

- Kr-79 sourced from Missouri reactor
- 35hr half-life, so only 3-4 days to complete surveys
- (Other longer-lived isotopes are available for tracing)
- 10cc (50mg) of Kr-78 in ampoule sent to reactor; only a small amount is converted to Kr-79





## Hawkins #1 RA Tracing




Wireless Radiation  
Detectors at Inlet,  
WH Outlet and Flowline  
(shielded circumferentially  
to avoid noise)





# 2025 GAS LIFT WORKSHOP



## Hawkins #1 RA Tracing



- Top valve closed, returns from valves 2 and 3, with more through bottom valve
- Choke had been opened and WHP had dropped to 110psi since CO<sub>2</sub> tracer run
- Noted well was producing more fluids with some slugs
- Hypothesized lower WHP helped close upper two valves
- **Results matched modeled nodal analysis predictions**
- **Tracer return times close to those seen with CO<sub>2</sub>**
- Detector responses not identical because thicker WH steel attenuates more than stainless flowline



## Hawkins #1 SF<sub>6</sub> Tracing





## Hawkins #1 SF<sub>6</sub> Tracing



- SF<sub>6</sub> injected, but no returns detected
- Determined afterward that dwell (sample) time was set too short for detection...after the fact
- Moved to next well due to limited SF<sub>6</sub>







# 2025 GAS LIFT WORKSHOP

## Hawkins #2 Pilot

## Hawkins #2 Baseline

- > 600BPD liquids, ~300 MCFD GL gas
- Three 12/64" IPOs, One 16/64" orifice
- Nodal: All returns through top valve
- Acoustic Shot: Only top valve open, others liquid-covered (backchecked)
- CO<sub>2</sub> Tracer: All returns through top valve, trip time about 2hr








# 2025 GAS LIFT WORKSHOP

## Hawkins #2 RA Tracing



Inlet Detector






# 2025 GAS LIFT WORKSHOP

## Hawkins #2 RA Tracing

- Single return from top valve
- Same transit time as CO<sub>2</sub>
- **Another match!**







## Hawkins #2 – SF<sub>6</sub> Tracing

SF<sub>6</sub> vapor pressure at ambient temp. was about 350psi, unable to quantify mass injected


- SF<sub>6</sub> normally liquid at injection conditions (same as CO<sub>2</sub>)
- Dip tube bottle enables liquid delivery when boosted with another high-pressure source (N<sub>2</sub> in this case)
- Dip tube bottle unavailable at testing location





## Hawkins #2 SF<sub>6</sub> Tracing

- Injected SF<sub>6</sub> and Ar
- No Ar detected, as expected from lab
- Looked for wider spectrum of SF<sub>6</sub> ions
- Detected tiny returns of SF<sub>6</sub> at 2.25hr, near CO<sub>2</sub> / RA peak times
- **Match, detection level = < 1ppm SF<sub>6</sub>!**
- 10,000x less tracer volume than CO<sub>2</sub>





## Next Steps

### RA Tracing

- Effective, non-intrusive, and available!
- Tracing economics highly dependent on RA isotope
- Kr-85 (10yr half-life) is preferred and  $\sim 1/10^{\text{th}}$  cost of Kr-79, but was unavailable—new supplier identification in progress

### SF<sub>6</sub> Tracing

- WH-internal sampler was an improvement over typical tracer setup
- Plan to repeat test with dip tube bottle
- A SF<sub>6</sub> specific measurement device could be even better
- May lead to automated GL tracing in the future...





Questions?





## References

1. *Dual GL Well Analysis Using WellTracer®* – **2010 ALRDC GL Workshop**, ExxonMobil
2. *Global GL Optimization Using WellTracer® Surveys* – **2013 ALRDC GL Workshop**, ExxonMobil
3. *Performance of Hawkins Field Unit Under Gas Drive-Pressure Maintenance Operations and Development of an Enhanced Oil Recovery Project* – **SPE/DOE-17324-MS**, Exxon Co. USA (1988)
4. *Performance and Expansion Plans for the Double-Displacement Process in the Hawkins Field Unit* – **SPE-28603-PA**, Exxon Co. USA (1995)
5. *Reservoir Simulation of Gas Injection Processes* – **SPE-81459-MS**, ExxonMobil Upstream Research Co. and ExxonMobil Production Co. (2003)



## Copyright

- Rights to this presentation are owned by the company(ies) and/or author(s) listed on the title page. By submitting this presentation to the Gas Lift Workshop, they grant to the Workshop, and the Artificial Lift Research and Development Council (ALRDC) rights to:
  - Display the presentation at the Workshop.
  - Place the presentation on the [www.alrdc.com](http://www.alrdc.com) web site, with access to the site to be as directed by the Workshop Steering Committee.
  - Place the presentation for distribution and/or sale as directed by the Workshop Steering Committee.
- Other uses of this presentation are prohibited without the expressed written permission of the company(ies) and/or author(s).



## Disclaimer

- The following disclaimer shall be included as the last page of a Technical Presentation or Continuing Education Course. A similar disclaimer is included on the Gas Lift Workshop webpage.
- The Artificial Lift Research and Development Council and its officers and trustees, and the Gas Lift Workshop Steering Committee members, and their supporting organizations and companies (here-in-after referred to as the Sponsoring Organizations), and the author(s) of this Technical Presentation or Continuing Education Course and their company(ies), provide this presentation and/or training material at the Gas Lift Workshop "as is" without any warranty of any kind, express or implied, as to the accuracy of the information or the products or services referred to by any presenter (in so far as such warranties may be excluded under any relevant law) and these members and their companies will not be liable for unlawful actions and any losses or damage that may result from use of any presentation as a consequence of any inaccuracies in, or any omission from, the information which therein may be contained.
- The views, opinions, and conclusions expressed in these presentations and/or training materials are those of the author and not necessarily those of the Sponsoring Organizations. The author is solely responsible for the content of the materials.
- The Sponsoring Organizations cannot and do not warrant the accuracy of these documents beyond the source documents, although we do make every attempt to work from authoritative sources. The Sponsoring Organizations provide these presentations and/or training materials as a service. The Sponsoring Organizations make no representations or warranties, express or implied, with respect to the presentations and/or training materials, or any part thereof, including any warranties of title, non-infringement of copyright or patent rights of others, merchantability, or fitness or suitability for any purpose.